


# Assembly Instructions

## ERS 50 Gravity Roller Conveyor



### Content:

ERS 50 STRAIGHT MODULE  
ERS 50 CURVE MODULE  
ERS 50 INFEEED - OUTFEED MODULE

**Manufacturer**

Swisslog GmbH  
Martin-Schmeißer-Weg 6-8  
44227 Dortmund  
Germany  
Tel. +49 231 75895 00  
www.swisslog.com  
[logistics@swisslog.com](mailto:logistics@swisslog.com)

**Copyright for this manual**

Swisslog GmbH holds the copyright on this manual. The manual contains standards, drawings and illustrations which may not be disclosed, published or duplicated, either fully or in part, not used for any other purpose than the installation referred to in this manual, without the prior written consent of Swisslog GmbH.

## Content

<b>1</b>	<b>GENERAL SAFETY INSTRUCTION .....</b>	<b>4</b>
1.1	TARGET GROUP .....	4
1.2	KEY TO SYMBOLS .....	4
1.3	REQUIREMENTS AND CONDITIONS .....	5
1.4	RISKS .....	8
<b>2</b>	<b>PRODUCT INFORMATION .....</b>	<b>10</b>
2.1	ERS 50 GRAVITY ROLLER CONVEYOR SYSTEM .....	10
2.2	ERS 50 STRAIGHT MODULE .....	10
2.3	ERS 50 CURVE MODULE .....	10
2.5	ERS SUPPORT .....	11
2.6	ERS SENSOR AND REFLECTOR .....	11
2.7	ERS SIDE GUIDE .....	11
2.8	ERS SIDE COVER PROFILE .....	11
2.9	ERS COVER CAPS .....	11
2.10	ERS STRAIGHT CONNECTOR .....	11
<b>3</b>	<b>TECHNICAL DATA .....</b>	<b>12</b>
3.1	ERS 50 STRAIGHT MODULE .....	12
3.2	ERS 50 CURVE MODULE .....	14
3.3	ERS 50 INFEED - OUTFEED MODULE .....	16
3.4	ERS SUPPORT .....	18
3.5	ERS SENSOR AND REFLECTOR .....	19
3.6	ERS SIDE GUIDE .....	20
3.7	ERS SIDE COVER PROFILE .....	21
3.8	ERS COVER CAPS .....	22
3.9	ERS STRAIGHT CONNECTOR .....	23
<b>4</b>	<b>TRANSPORTATION .....</b>	<b>24</b>
<b>5</b>	<b>ASSEMBLY AND INSTALLATION .....</b>	<b>25</b>
5.1	GENERAL INFORMATION .....	25
5.2	ERS 50 COUPLING GRAVITY CONVEYOR MODULES .....	28
5.3	ERS 50 INFEED – OUTFEED MODULE .....	29
5.4	ERS 60 SUPPORT .....	31
5.5	ERS SENSOR AND REFLECTOR .....	32
5.6	ERS SIDE GUIDES .....	34
5.7	ERS SIDE COVER PROFILE AND ERS COVER CAPS .....	36
<b>6</b>	<b>CLEANING, MAINTENANCE AND REPLACEMENTS .....</b>	<b>37</b>
6.1	GENERAL INFORMATION .....	37
6.2	ERS 50 STRAIGHT / CURVE / INFEED / OUTFEED .....	39
6.3	ERS SENSOR AND REFLECTOR .....	45
6.4	ERS SIDE GUIDE .....	47
6.5	ERS SIDE COVER PROFILE .....	49
6.6	ERS COVER CAPS .....	50
6.7	ERS STRAIGHT CONNECTOR .....	51
<b>7</b>	<b>STORAGE AND DISPOSAL .....</b>	<b>52</b>

7.1 STORAGE.....52

7.2 DISPOSAL .....52

**8 APPENDIX..... 52**

TABLE SHEET INFEED – OUTFEED MODULE .....53

DECLARATION OF INCORPORATION OF PARTLY COMPLETED MACHINERY.....54





## 1 General Safety Instruction

### 1.1 Target Group






This documentation is aimed at users with the following knowledge and skills:


- Advanced knowledge of mechanical engineering
- Advanced knowledge of electrical engineering

### 1.2 Key to Symbols



	<p><b>Caution</b></p> <p>For your personal safety please precisely observe the working and operating procedures</p>
	<p><b>Warning</b></p> <p>Observe all instructions and procedures, in order to maintain your plant in working condition.</p>
	<p><b>Note</b></p> <p>In order to keep the machine in working order, observe precisely all technical requirements for appropriate handling of the machine.</p>
	<p><b>Additional information</b></p> <p>Helps you to make optimum use of all the functions on your machine.</p>

## 1.3 Requirements and Conditions

	<b>Supplement to the documentation</b> <ul style="list-style-type: none"> <li>- Generally applicable and local rules for accident prevention.</li> <li>- Law on staff protection.</li> <li>- Regulations on the protection of the environment.</li> </ul>
	<b>Qualification of staff</b> <ul style="list-style-type: none"> <li>- You have the required training.</li> <li>- You are thoroughly familiar with the use of the plant.</li> <li>- You are familiar with the documentation contents.</li> </ul>
	<b>Safe operation</b> <ul style="list-style-type: none"> <li>- There are no persons or obstacles in the danger areas.</li> <li>- Shut down operation at once when there is a threat of danger.</li> <li>- Regular inspection and maintenance keeps your plant ready for use.</li> <li>- Immediately rectify any defects or damage which occurs.</li> <li>- Ensure all use is for the purpose intended.</li> <li>- Protective equipment is fitted professionally and is fully functional.</li> <li>- Safety and danger notices must be fully legible.</li> </ul>
	<b>Explanation of terminology</b> <p>Maintenance: Measures for upkeep and repairs of the projected status and also determining and assessing the actual status of the technical devices of a system. The measures comprise:</p> <ul style="list-style-type: none"> <li>- Inspection</li> <li>- Servicing</li> <li>- Repairs</li> </ul>
	<b>Safe maintenance</b> <ul style="list-style-type: none"> <li>- Access to the plant is forbidden for all unauthorized persons.</li> <li>- You are thoroughly aware of all sources of danger.</li> <li>- You have switched off the main switch and secured it against being switched on again.</li> <li>- You access the plant only at those points designed for access.</li> <li>- Never ignore or fail to use safety equipment.</li> <li>- Always observe the safety notices.</li> </ul>




	<p><b>Correct maintenance</b></p> <ul style="list-style-type: none"> <li>- Appropriately trained maintenance staff.</li> <li>- You are familiar with the maintenance measures.</li> <li>- You have completed the tests required within the time period laid down.</li> <li>- You use suitable tools.</li> <li>- Immediately rectify any defects or damage which occurs.</li> </ul>
---	--

## 1.3.1 Special safety devices


	<p><b>Protective measures</b></p> <ul style="list-style-type: none"> <li>- Machine movements are dangerous.</li> <li>- Danger areas of this kind are to be separated from the rest of the plant by protective screens, Plexiglas barriers, etc. and marked with safety warning notices.</li> </ul>
	<p><b>Further safety devices</b></p> <ul style="list-style-type: none"> <li>- See documentation on electrical system, controls.</li> </ul>

## 1.3.2 Intended use and misuse

### Intended use


	<p><b>Products to be transported</b></p> <ul style="list-style-type: none"> <li>- You must not exceed the maximum load capacity.</li> </ul>
	<p><b>Products to be transported</b></p> <ul style="list-style-type: none"> <li>- The load must not project more than the amount foreseen above the carrier, in order to avoid tipping, catching or falling.</li> <li>- The carrier must be in a satisfactory condition.</li> </ul>
	<p><b>Plant</b></p> <ul style="list-style-type: none"> <li>- You must observe the generally valid safety notices.</li> <li>- You must observe the maintenance regulations.</li> </ul>

## Misuse

	<p><b>Not permitted is</b></p> <p>The transport of:</p> <ul style="list-style-type: none"> <li>- Explosives, highly inflammable or radioactive materials.</li> <li>- Fluids not in closed barrels.</li> <li>- Materials to which special hygienic regulations apply.</li> <li>- Parts with high electrical potential and magnetic fields.</li> <li>- Live animals.</li> <li>- The removal of or ignoring of safety equipment.</li> <li>- The ignoring of safety notices.</li> </ul>
---	---

### 1.3.3 Special Regulations

These regulations apply when working with the ERS Gravity Roller Conveyors.

	<p><b>Clothing &amp; Appearance</b></p> <ul style="list-style-type: none"> <li>- Wear suitable work clothes and Personal Protection Equipment (no loose hanging clothes, safety shoes, gloves, etc.).</li> <li>- Tie up long hair or wear a cap or hairnet.</li> <li>- Remove jewellery (necklaces, rings, bracelets, watches, etc.).</li> </ul>
---	--



## 1.4 Risks

Danger	Cause	Avoidance
Permanent injury to the area of the spine  Permanent injury to the area of the wrist	Excessive bodily strain during manual lifting of the products	Do not manually lift the product  Use appropriate lifting equipment
Serious injury to hands	Clamping of hands between moving objects  Catching of clothing / jewellery in moving machine parts during maintenance / operation	Do not touch the product when connected to a power source  Observe the general safety notices  Approved working clothes  Remove jewellery
Serious injury to head	Catching of hair in moving machine parts during maintenance / operation	In case of long hair, bind them together or wear a hairnet or cap
Serious injury to body parts	Falling of products during manual removal e.g. after a failure of the machine controls	Use of safety straps  Do not lift products exceeding specified weight limits  Use of protective gloves with grip coating
Serious injury to body parts	Falling of products from conveyor	If conveyor is placed overhead, make sure to place protection against falling products around the conveyor  Place side guard  Provide a stop at the end of each conveyor

Danger	Cause	Avoidance
Serious injury to body parts	During set up, sharp edges of the frame are accessible	<p>Wear protective gloves during handling of the conveyor</p> <p>Wear protective gloves during set up of the conveyor</p> <p>Place cover caps after set up and installation of the conveyor</p>
Serious injury to body parts	Uncontrolled movement of products on a declined gravity roller conveyor	<p>If a gravity roller conveyor is used in a declined position, a risk assessment should be performed,</p> <p>Apply brake rollers into the gravity roller conveyor to control the movement of products</p>

## 2 Product Information


### 2.1 ERS 50 Gravity Roller Conveyor system

#### 2.1.1 Product Description

The ERS Gravity Roller Conveyor System is a modular system used to transport products. The ERS Gravity Roller Conveyor System provides a low noise, high volume solution. The throughput of the standard ERS Gravity Roller Conveyor System depends on the weight and dimensions of the transported products.

The ERS Gravity Roller Conveyor System consists of the following principal components:

- ERS 50 Straight Module
- ERS 50 Curve Module
- ERS 50 Infeed - Outfeed Module



### 2.2 ERS 50 Straight Module

The ERS Straight Module is a straight gravity roller conveyor, used to transport products in a straight line. The ERS Straight Module provides a low noise, high volume solution. The throughput of the standard ERS Straight Module depends on the weight and dimensions of the transported products.

ERS 50 Curve Module

### 2.3 ERS 50 Curve Module

The ERS Curve Module is a curved gravity roller conveyor, used to transport products in a curve. The ERS Curve Module provides a low noise, high volume solution. The throughput of the standard ERS Curve Module depends on the weight and dimensions of the transported products.

ERS 50 Infeed - Outfeed Module

## **2.4 ERS 50 Infeed – Outfeed Module**

The ERS Infeed / Outfeed Module is a gravity roller conveyor, used to merge / divide transport products. The ERS Infeed / Outfeed Module provides a low noise, high volume solution. The throughput of the standard ERS Infeed / Outfeed Module depends on the weight and dimensions of the transported products.

## **2.5 ERS Support**

The ERS Gravity Roller Conveyor needs to be supported by a suitable supporting system in at least every 1.5 m distance. The supporting system has to be mounted with M8 hammerhead bolts onto the side profiles of the ERS Gravity Roller Conveyor.

### **2.5.1 ERS 60 Support**

The ERS 60 Support could be used to support a roller conveyor and is placed underneath a roller conveyor and is bolted onto the ground.

## **2.6 ERS Sensor and Reflector**

The ERS Sensor is a photocell based sensor used to detect an object or to control a zone of a ERS Gravity Roller Conveyor. The sensor can be integrated in High Profile Conveyors Modules or added to the Low Profile Conveyors Modules with a dedicated mounting brackets.

## **2.7 ERS Side Guide**

The ERS Side Guide is used to guide conveyed objects on the ERS Gravity Roller Conveyor. The guide can be integrated on the Low Profile Conveyor Modules using the dedicated mounting brackets. There are two types of brackets; a fixed guide bracket and an adjustable guide bracket.

## **2.8 ERS Side Cover Profile**

The ERS Side Covers profiles are used to cover the sides of the ERS Gravity Roller Conveyor profiles.

## **2.9 ERS Cover Caps**


The ERS Cover Caps are used to cover the edges on the front and back side of the ERS Gravity Roller Conveyor profiles. The ERS Cover Caps are available for high and low profiles.



## **2.10 ERS Straight Connector**

The ERS Straight Connector is used to connect multiple ERS Gravity Roller Conveyors. The connector is equipped with a plastic screen cover.


### 3 Technical data



#### 3.1 ERS 50 Straight Module

General technical data	
Max. load capacity	100 kg
Inclined / Declined	Suitable for decline
Ambient temperature	-5°C to +50°C
Humidity	Maximum 90%, no condensation
Noise emission	70 < dB(A) (value can vary on installation conditions)
	<b>Maximum load capacity is depending on the combination of speed &amp; load</b>
Rollers	
Roller diameter	Ø 50 mm
Roller material	Steel, galvanised
Side profile	
H profile (high)	151.5 mm high 31.5 mm from top edge of the roller
L profile (low)	Maximum sideways shift 116 mm high 4 mm from top edge of the roller
Combinations (left/right)	
Dimensions	
LW dimension	420/520/620/820 mm
TW - Module width	LW + 75 mm
P Roller separation	75/100 mm
Sp - Side profile	116/151.5 mm
SF - Side guide	31.5 mm






### 3.2 ERS 50 Curve Module


General technical data	
Max. load capacity	100 kg
Inclined / Declined	Not Suitable
Ambient temperature	-5°C to +50°C
Humidity	Maximum 90%, no condensation
Noise emission	70 < dB(A) (value can vary on installation conditions)
Maximum load capacity is depending on the combination of speed & load	
Rollers	
Roller diameter	Ø 50 mm
Roller material	Steel with grey conical plastic elements
Side profile	
H profile (high)	151.5 mm high 31.5 mm from top edge of the roller
L profile (low)	Maximum sideways shift 116 mm high 4 mm from top edge of the roller
Combinations (left/right)	
Dimensions	
LW dimension	420/520/620/820 mm
TW - Module width	LW + 75 mm
α-angle	30°/45°/60°/90°
P Roller separation, external	~ (0.087 mm x LW) + Pi
Pi Roller separation, internal	~72 mm
Sp - Side profile	116/151.5 mm
SF - Side guide	31.5 mm





### 3.3 ERS 50 Infeed - Outfeed Module

General technical data	
Max. load capacity	100 kg
Inclined / Declined	Suitable for decline
Ambient temperature	-5°C to +50°C
Humidity	Maximum 90%, no condensation
Noise emission	70 < dB(A) (value can vary on installation conditions)
Maximum load capacity is depending on the combination of speed & load	
Rollers	
Roller diameter	Ø 50 mm
Roller material	Steel, galvanised
Side profile	
H profile (high)	151.5 mm high 31.5 mm from top edge of the roller 
L profile (low)	Maximum sideways shift 116 mm high 4 mm from top edge of the roller 
Combinations (left/right)	
Dimensions	
LW dimension	420/520/620/820 mm
TW - Module width	LW + 75 mm
F Front length	See attachment: Table sheet Infeed – Outfeed Module
α-angle	30°/45°
P Roller separation	75 mm
Sp - Side profile	116/151.5 mm
SF - Side guide	31.5 mm





## 3.4 ERS Support

General requirements	
Max. horizontal load capacity	Depends on the conveyor type and load
Max. vertical load capacity	Depends on the conveyor type and load
Max. pitch	1500 mm
<div style="display: flex; align-items: center;"> <div style="background-color: #005596; color: white; padding: 5px; margin-right: 10px; text-align: center;">i</div> <div>For further information, see the ERS 69 Steel Supports - Assembly Instructions.</div> </div>	

### 3.4.1 ERS 60 Support

### 3.4.2


General technical data	
Max. load capacity	200 kg
Number of cross-members	1 with 350 to 800 mm top edge of roller
	2 with 800 to 1400 mm top edge of roller
	3 with 1400 to 2000 mm top edge of roller
Dimensions	
LW dimension	420/520/620/820 mm
Height to top side of rollers	362 to 2000 mm




## 3.5 ERS Sensor and Reflector

General technical data	
Operating range	0.02 ... 4.5 m, With reflector TK(S) 100x100
Light source	LED, RED
Supply voltage	10 ... 30 V, DC
Open-circuit current	0 ... 20 mA
Weight (sensor only)	20 g
Operation temperature	-40 ... 60 °C
<b>Bracket</b>	
Weight	660 g
<b>Clip</b>	
Weight	3 g

Sensor Bracket




Sensor Clip



	More variations available, please refer to the Additional Parts Assembly Instruction.
--	---

## 3.6 ERS Side Guide

General technical data	
Adjustable Guide Bracket	
Roller conveyor profile	Low
Adjustability range (height)	50 mm
Adjustability range (track width)	50 mm
Suitable for curved conveyor track	Yes
Number of brackets in curve track	$90^\circ = 7 / 60^\circ = 5 / 45^\circ = 5 / 30^\circ = 4$
Number of brackets straight track	Every 0.5 m
Weight	660 g
Fixed Guide Bracket	
Roller conveyor profile	Low
Suitable for curved conveyor track	No
Number of brackets straight track	Every 0.5 m
Weight	430 g
Guides	
Side Guide Profile order length	5600 mm
Weight	1940 g
Guide Wear Strip order length	3000 mm
Weight	650 g



Side Guide Profile




Guide Wear Strip




Guide End



	More variations available, please refer to the Additional Parts Assembly Instruction.
---	---


### 3.7 ERS Side Cover Profile

General technical data	
Dimensions	
Side Cover Profile order length	3000 mm
Weight	826 g




### 3.8 ERS Cover Caps

General technical data	
Dimensions	
High profile Cover Cap weight	16 g
Low profile Cover Cap weight	12 g




### 3.9 ERS Straight Connector



General technical data	
Dimensions	
Weight	476 g






## 4 Transportation

	<p><b>Transportation</b></p> <ul style="list-style-type: none"> <li>- Only qualified and authorized personnel should transport the packaged ERS Gravity Roller Conveyor System.</li> <li>- If packaged contents are unstable, unload the package unit by unit and not by truck.</li> <li>- When unpacked only transport single modules, unless they are already coupled before transportation by the supplier.</li> <li>- Wear protective clothing, gloves and shoes during handling of the conveyor. Sharp edges are exposed.</li> <li>- Be aware that the center of gravity is not always in the middle of the Conveyor Module.</li> </ul>
---	--



## 5 Assembly and installation


	<p><b>Installation</b></p> <ul style="list-style-type: none"> <li>- As the ERS Gravity Roller Conveyor Modules are a partial system of an overall installation, you need to perform a risk analysis of the entire installation.</li> <li>- Identify the protective measures required concerning risks related to local conditions at the site and to usage.</li> <li>- Define a safety zone in the working area.</li> <li>- Secure the zone and set up proper signaling and appropriate protection</li> <li>- For assembling modules at special heights, refer to safety rules concerning working on heights.</li> <li>- Never climb or walk on top of the ERS Gravity Roller Conveyor Modules.</li> <li>- During assembly wear appropriate Personal Protective Equipment.</li> <li>- Always provide a control circuit with at least:             <ul style="list-style-type: none"> <li>- Main switch</li> <li>- Start–Stop function,</li> <li>- Emergency stop</li> </ul> </li> <li>- The control circuit has to be made according to EN-IEC 60204-1</li> <li>- The emergency stop system has to be made according to EN-ISO13850</li> </ul>
---	--

### 5.1 General Information

#### 5.1.1 Assembly rules

The assembly method provided by Swisslog Technology Center Netherlands is a guide line in how to assemble the different modules. Always adapt the provided assembly method to the national and local safety rules and requirements.

The ERS Gravity Roller Conveyor Modules will always be delivered pre-assembled.

	<p><b>Edited components</b></p> <p>If any changes are made to the components or their location in the lanes, then Swisslog Technology Center Netherlands is no longer responsible for the product, as this represents unintended use of the ERS Gravity Roller Conveyor Modules.</p>
---	--

## 5.1.2 Qualified Personnel

Assembly and installation of the ERS Gravity Roller Conveyor Modules can only be done by properly instructed personnel. This personnel must be under the supervision of a manager who is technically competent and trained concerning the following:

- The products and their use.
- The dangers inherent in the assembly of heavy components.
- The risks related to incorrect assembly.
- The adjustments required for correct operation of the ERS Gravity Roller Conveyor Modules.

## 5.1.3 General Rules




Before starting the assembly take account for the following:

- Comply with the designed layout.
- Before starting assembly, clean the work site to create a safe environment.
- If other systems connect to the ERS Gravity Roller Conveyor Modules, use the same reference points to level the systems.
- Before unpacking the shipped ERS Gravity Roller Conveyor Modules, check the stability before remove packaging.
- Make sure you do not damage the ERS Gravity Roller Conveyor Modules.
- After assembly and before testing clean the work environment. Do not leave any spare parts or tools in the work site and surrounding areas.



## 5.1.4 Assembly

The ERS Gravity Roller Conveyor Modules, are always delivered completely assembled (up to 3 meters in length). The final assembly on site should only consist out of the following:


1. Mounting Support Stands or Support.
2. Coupling of Modules.
3. Wiring.

	<p><b>Mounting</b></p> <p>Always mount a support stand or similar to the ground or another solid part of a construction.</p>
	<p><b>Coupling</b></p> <p>Before coupling the different sections always place the sections on a support stand or Support. Never couple sections without proper support. Do not transport sections when connected, this could possibly cause failures.</p>
	<p><b>Wiring</b></p> <p>For wiring instructions check manufactures website or check the dealer section on our website for applicable user manuals.</p>

## 5.1.5 Start-up checks

	<p><b>Visual safety check</b></p> <ul style="list-style-type: none"> <li>- When connecting the ERS Gravity Roller Conveyor Modules to another machine or system perform a risk analysis of the entire installation.</li> <li>- Check the installed modules for damage.</li> <li>- Check the working area for foreign material in the working area.</li> <li>- Check that all signage is in place (max. load capacity and restriction for use).</li> </ul>
	<p><b>Safety check</b></p> <ul style="list-style-type: none"> <li>- Check all personnel are properly instructed before working with or near the ERS Gravity Roller Conveyor Modules.</li> <li>- Check for visible damage on the ERS Gravity Roller Conveyor Modules.</li> <li>- Check for foreign material preventing correct operation.</li> </ul>

## 5.1.6 Operation

	<p><b>In operation</b></p> <p>Close down a system or ERS Gravity Roller Conveyor Modules Module if any of the following occurs:</p> <ul style="list-style-type: none"> <li>- Suspicious noise from any of the component.</li> <li>- A visibly worn or damaged component.</li> <li>- Damage to structural components such as frame and support.</li> </ul>
---	---

## 5.1.7 In case of an accident

1. Stop the ERS Gravity Roller Conveyor Modules.
2. Secure the area and set up appropriate signage.
3. In the event of an accident: provide first aid and call the emergency services.
4. Inform qualified personnel.
5. Have the system repaired by qualified maintenance personnel.
6. Do not use the ERS Gravity Roller Conveyor Modules until authorized by qualified maintenance personnel.

## 5.2 ERS 50 Coupling Gravity Conveyor Modules

### 5.2.1 Couple/uncouple of ERS Modules

Before coupling of the different ERS Gravity Roller Conveyor Modules could take place, the modules must be mounted on support stands.


**Step 1** Place two ERS Gravity Roller Conveyor Modules next to each other and slide Straight Connectors into both sides of the side profile of one of the ERS Gravity Roller Conveyor Modules.

**Step 2** Align the ERS Gravity Roller Conveyor Modules.

**Step 3** Slide the Straight Connectors halfway onto both modules.

**Step 4** Tighten the M8 bolts with a torque of 23 Nm.

For uncoupling, repeat the steps above in reverse order.



## 5.3 ERS 50 Infeed – Outfeed Module

### 5.3.1 Mounting/ dismounting the ERS 50 Infeed - Outfeed Module

The Infeed – Outfeed Module could be connected to the side profile of the Straight Module, using clamping plates. The Infeed – Outfeed Module could only be connected to the side where no zone controller is attached.


**Step 1** Hoist and hang an Infeed – Outfeed Module next to a Straight Module, using appropriate lifting equipment.


**Step 2** Tilt the Infeed – Outfeed Module downward so the clamping plates fit into the side profile of the Straight Module.

**Step 3** Tilt the Infeed – Outfeed Module horizontal.

**Step 4** Tighten the M8 bolts with a torque of 23 Nm.

For dismounting the Infeed – Outfeed Module, repeat the steps above in reverse order.





## 5.4 ERS 60 Support

### 5.4.1 Mounting/ dismounting the ERS 60 Support

Before coupling of the different modules could take place, the modules must be mounted on support stands. Supports are attached with four M8 hammerhead bolts and torque nuts onto the side profiles of the module.

**Step 1** Hoist and hang a roller conveyor module above the ground, 100 mm higher than the Support height, using appropriate lifting equipment.


**Step 2** Slide two Supports provided with M8 hammerhead bolts into each side of the roller conveyor module.

**Step 3** Slide the Supports to the desired place.

**Step 4** Place the M8 torque nuts onto the hammerhead bolts and tighten them.

**Step 5** Lower the roller conveyor onto the ground.

For dismounting the Supports, repeat the steps above in reverse order.





## 5.5 ERS Sensor and Reflector

### 5.5.1 Mounting/ dismounting the ERS Sensor and Reflector – Sensor Clip

A High Profile ERS Gravity Roller Conveyor Module is equipped with dedicated mounting holes for the Sensorclip.


**Step 1** Place the ERS Sensor in the Sensorclip as shown in the illustration

**Step 2** Determine the desired position of the sensor.

**Step 3** Push-click the clip with sensor in the corresponding hole.

**Step 4** Place the reflector in line with the sensor on the opposite side of the roller conveyor.

For dismounting the Sensor and Reflector, repeat the steps above in reverse order.



### 5.5.2 Mounting/ dismounting the ERS Sensor and Reflector – Sensor Bracket

The Sensor bracket is suitable for Low Profile ERS Gravity Roller Conveyor Modules.

**Step 1** Loosen the two M8 Bolts.

**Step 2** Determine the desired position of the Sensor.

**Step 3** Place the bracket on the roller conveyor as shown in the illustration below.


**Step 4** Clamp the bracket to the Straight Module by tightening the M8 Bolts.

**Step 5** Optional: Adjust the height and rotation by loosening the M12 nut.

**Step 6** Optional: Adjust the orientation of the sensor with the Sensor set screw.

**Step 7** For mounting the Reflector bracket repeat the steps above. Place the reflector in line with the sensor on the opposite side of the roller conveyor.

For dismounting the Sensor or Reflector, repeat the steps above in reverse order.



## 5.6 ERS Side Guides

### 5.6.1 Mounting/ dismantling the ERS Side Guide – Fixed Bracket Type

The ERS Side Guide Fixed Bracket is mounted on the low profile ERS Gravity Roller Conveyor Modules. The Fixed Bracket is not suitable for bended ERS Gravity Roller Conveyor Modules. The Side Guide Profile and the Guide Wear Strip should be cut to the desired length with a proper cutting tool. The Guide Wear Strip should be 50 mm longer than the Side Guide Profile to properly assemble the Guide Ends.

**Step 1** Define the required amount of brackets (can be found in the product description).

**Step 2** Loosen the M8 Bolts of the fixed bracket(s).


**Step 3** Place the bracket(s) on the roller conveyor at the desired location and tighten the M8 Bolts.

**Step 4** Slide the Side Guide Profile over the Guide Bolt and tighten it.

**Step 5** Slide the Guide Wear Strip over the Side Guide Profile.

**Step 6** Place the Guide End on both sides of the Side Guide.

For dismantling the ERS Side Guide, repeat the steps above in reverse order.



### 5.6.2 Mounting/ dismantling the ERS Side Guide – Adjustable Bracket Type

The ERS Side Guide Adjustable Bracket is mounted on the low profile ERS Gravity Roller Conveyor Modules. The Adjustable Bracket is suitable for curved ERS Gravity Roller Conveyor Modules. In case of a curved module, the ERS Side Guide Profile should be bent with a dedicated bending machine. The Side Guide Profile and the Guide Wear Strip should be cut to the desired length with a proper cutting tool. The Guide Wear Strip should be 50 mm longer than the Side Guide Profile to properly assemble the Guide Ends.

**Step 1** Define the required amount of brackets (can be found in the product description).

**Step 2** Loosen the M8 Bolts of the adjustable bracket(s).


**Step 3** Place the bracket(s) on the roller conveyor at the desired location and tighten the M8 Bolts.

**Step 4** Slide the Side Guide Profile over the two Guide Bolts and tighten them.

**Step 5** Slide the Guide Wear Strip over the Side Guide Profile.

**Step 6** Place the Guide End on both sides of the Side Guide.

For dismantling the ERS Side Guide, repeat the steps above in reverse order.



## 5.7 ERS Side Cover Profile and ERS Cover Caps


### 5.7.1 Mounting/ dismantling the ERS Side Cover Profile and ERS Cover Caps

The ERS Side cover Profile and ERS Cover Caps are mounted on the ERS Gravity Roller Conveyor Module side profiles. The ERS Side Cover Profile should be cut to the desired length with a proper cutting tool.

**Step 1** Define the required length of the ERS Side Cover Profile and cut the profile to the desired length.

**Step 2** Slide in or push in the ERS Side cover Profile and ERS Cover Caps.

For dismantling the ERS Side Cover Profile and ERS Cover Caps, repeat the steps above in reverse order.



## 6 Cleaning, Maintenance and Replacements

Make sure the ERS Gravity Roller Conveyor Module is disconnected from the power source when carrying out cleaning, maintenance or replacements.

### 6.1 General information

#### 6.1.1 Cleaning Information

<div data-bbox="256 566 507 613" data-label="Image"> </div>	<p><b>Products</b></p> <ul style="list-style-type: none"> <li>- Do not use abrasive products, pressurized jets or products which may cause oxidization or damage the equipment.</li> <li>- Clean the ERS Gravity Roller Conveyor Modules using a dry cloth.</li> </ul>
---	--

#### 6.1.2 Maintenance Information

<div data-bbox="256 1010 507 1059" data-label="Image"> </div>	<p><b>Safety</b></p> <ul style="list-style-type: none"> <li>- Make sure maintenance is carried out by qualified personnel who are familiar with the proper procedures and instructions.</li> <li>- Secure the working area and shut down the machinery and apply appropriate signage. Make sure nobody can start up the machinery during maintenance.</li> <li>- Wear Personal Protective Equipment.</li> <li>- When in doubt contact the supplier or manufacturer of the parts.</li> <li>- Make sure the complete system is disconnected from the power source when carrying out cleaning, maintenance or replacements.</li> </ul>
<div data-bbox="256 1458 507 1507" data-label="Image"> </div>	<p><b>Third party spare parts</b></p> <p>Some parts are used from third parties, mostly electronics. In case of the ERS Gravity Roller Conveyor Modules this can be:</p> <ul style="list-style-type: none"> <li>- Inductive Sensors</li> </ul> <p>The third parties deliver these parts with stand-alone user manuals. Please check the appendix or visit the manufacturer's website for additional maintenance and mounting information.</p>

## 6.1.3 Maintenance intervals

defines the maintenance intervals according to the **operating hours**. During these periods, The ERS Gravity Roller Conveyor System has to be disconnected from the electrical network, cleaned, and investigated for wear. Faults observed during the inspections and unforeseen changes must be corrected immediately.


The maintenance activities are to be performed as listed.

Working period In hours per day	Interval In months
0-8	3
8-16	2
16-24	1

If maintenance is not performed as scheduled, damage can occur. If maintenance intervals are not complied with, guarantee expires.

## 6.2 ERS 50 Straight / Curve / Infeed / Outfeed

### 6.2.1 Maintenance



	Part	Inspection	Result	Action
1.	Tap Roller	Mounting check	Mounting bolt too loose	Tighten
		Acoustic check	Noise	Replace Tap Roller
		Visual check	Damaged Roller	Replace Tap Roller
2.	Roller	Acoustic check	Noise	Replace Roller
		Visual check	Damaged Roller	Replace Roller



## 6.2.2 Replacements

### 6.2.2.1 Roller Replacement



Make sure the Module is disconnected from the power source when carrying out cleaning, maintenance or replacements.

#### Step 1.


Push in the hexagonal head on one end of the roller.

#### Step 2.

Tilt and lift the Roller.

#### Step 3.

Replacing the Roller could be done by repeating the steps in reverse order.



## 6.2.2.2 Tap Roller Replacement



Make sure the Module is disconnected from the power source when carrying out cleaning, maintenance or replacements.

### Step 1.


Remove the M8 Bolts on both sides of the roller.

### Step 2.

Tilt and lift the Roller.


### Step 3.

Replacing the Roller could be done by repeating the steps in reverse order.




## 6.2.3 Spare parts

### 6.2.3.1 ERS Straight Module




POS.	ART. NUMBER	WIDTH(LW)	COMMENT
1	ERS040308170420	420	Tap Roller
	ERS040308170520	520	Tap Roller
	ERS040308170620	620	Tap Roller
	ERS040308170820	820	Tap Roller
2	ERS040308000420	420	Roller
	ERS040308000520	520	Roller
	ERS040308000620	620	Roller
	ERS040308000820	820	Roller

6.2.3.2 ERS Curve Module




POS.	ART. NUMBER	WIDTH(LW)	COMMENT
1	ERS040308020420	420	Tapered Roller
	ERS040308020520	520	Tapered Roller
	ERS040308020620	620	Tapered Roller
	ERS040308020820	820	Tapered Roller

6.2.3.3 ERS Infeed - Outfeed Module




POS.	ART. NUMBER	WIDTH(LW)	COMMENT
1	ERS040308170420	420	Tap Roller
	ERS040308170520	520	Tap Roller
	ERS040308170620	620	Tap Roller
	ERS040308170820	820	Tap Roller
2	ERS040308000420	420	Roller
	ERS040308000520	520	Roller
	ERS040308000620	620	Roller
	ERS040308000820	820	Roller
3-7	ERS040308170xxx*	-	Merge Roller
*	Example:	Width of Merge Roller =	115 mm
		xxx =	115
		Art. number =	ERS040308170 <u>115</u>



## 6.3 ERS Sensor and Reflector


### 6.3.1 Maintenance



	Part	Inspection	Result	Action
1.	Sensor	Visual check	LED not burning	Check / Replace Wiring  Check Power Supply  Replace Sensor
2.	Bracket	Visual Check	Misalignment  Disjointed	Adjust height  Adjust orientation  Tighten joint M8 Bolts

## 6.3.2 Spare parts


### 6.3.2.1 ERS Sensor and Reflector



POS.	ART. NUMBER	WIDTH(LW)	COMMENT
1	040310010003	-	Sensor, Leuze PRK5/4P-M8
2	ERS040311020000	-	Sensor Bracket
3	040310010001	-	Reflector
4	ERS040311020001	-	Reflector Bracket
5	ERS090315000000 040306070001	-	Sensor Clip

## 6.4 ERS Side Guide

### 6.4.1 Maintenance




	Part	Inspection	Result	Action
1.	Fixed Guide Bracket	Visual Check	Disjointed	Tighten joint M8 Bolts Replace Bracket
2.	Adjustable Guide Bracket	Visual Check	Misalignment  Disjointed	Adjust height  Adjust orientation  Tighten joint M8 Bolts Replace Bracket
3.	Side Guide Profile	Visual Check	Cracks/ Broken	Replace Side Guide Profile
4.	Guide Wear Strip	Visual Check	Cracks/ Broken	Replace Guide Wear Strip
5.	Guide End	Visual Check	Cracks/ Broken	Replace Guide End



## 6.4.2 Spare parts

### 6.4.2.1 ERS Side Guide




POS.	ART. NUMBER	WIDTH(LW)	COMMENT
1	ECP040103000000	-	Guide Wear Strip (3000 mm)
2	ERS040311000002	-	Adjustable Guide Bracket
3	ETS040809050000	-	Guide End
4	ETS040809000000	-	Side Guide Profile (5600 mm)
5	ERS040311010000	-	Fixed Guide Bracket

6.5 ERS Side Cover Profile

6.5.1 Spare parts

6.5.1.1 ERS Side Cover Profile




POS.	ART. NUMBER	WIDTH(LW )	COMMENT
1	040307000002	-	ERS Side Cover Profile (3000 mm)

## 6.6 ERS Cover Caps

### 6.6.1 Spare parts

#### 6.6.1.1 ERS Cover Caps




POS.	ART. NUMBER	WIDTH(LW )	COMMENT
1	040306080001	-	Cover Cap Right High
2	040306080002	-	Cover Cap Left High
3	040306080003	-	Cover Cap Right Low
4	040306080004	-	Cover Cap Left Low

6.7 ERS Straight Connector

6.7.1 Spare parts


6.7.1.1 ERS Straight Connector




POS.	ART. NUMBER	WIDTH(LW )	COMMENT
1	ERS04030504000	-	ERS Straight Connector

## 7 Storage and disposal

### 7.1 Storage

	<p><b>Storage</b></p> <ul style="list-style-type: none"> <li>- Store the ERS Gravity Roller Conveyor Modules indoors.</li> <li>- Never store the ERS Gravity Roller Conveyor Modules outdoors, in a dusty or in a humid environment.</li> <li>- Do not add additional loads unto the packaged ERS Gravity Roller Conveyor Modules.</li> </ul>
---	---

### 7.2 Disposal

	<p><b>Disposal</b></p> <p>When the ERS roller Conveyor Module reaches the end of its useful life, it can be removed from the system and dismantled and the materials can be disposed of properly by type. For the correct proposal please check your local waste disposal regulations!</p>
---	--

## 8 Appendix

Attachments:

- Table Sheet Infeed – Outfeed Module
- Declaration of Incorporation of partly completed machinery

Manuals:

- Photoelectric sensor, Leuze PRK5/4P-M8

## Table sheet Infeed – Outfeed Module

### Dimensions of Infeed – Outfeed Module

The angles and separations of an Infeed – Outfeed module define the dimensions of the module. The following tables show the standard dimensions for the modules.

Dimension LW in mm	Dimension LWT in mm	Module width ML in mm	Front length F in mm	Module width ML in mm	Front length F in mm
		with angle $\alpha = 45^\circ$ and roller pitch $P = 75$ mm		with angle $\alpha = 45^\circ$ and roller pitch $P = 75$ mm	
420	420	900	637.5	1200	937.5
520	420	900	637.5	1200	937.5
620	420	900	637.5	1200	937.5
820	420	900	637.5	1200	937.5
420	620	1200	787.5	1500	1312.5
520	620	1200	787.5	1500	1312.5
620	620	1200	787.5	1500	1312.5
820	620	1200	787.5	1500	1312.5
620	820	1500	1012.5	1950	1612.5
820	820	1500	1012.5	1950	1612.5





## Appendix 1

List of essential requirements complied with in accordance with Annex I, Directive 2006/42/EC

General designation	QuickMove
Model/type designation	ERS 50, non-driven roller conveyor elements
Unique identification number	

Section	Requirements	To be complied with by the system integrator for the final machinery			Complied with for the scope of the partly completed machinery			Not relevant		
1.1.	GENERAL									
1.1.1.	Definitions	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>						
1.1.2.	Principles of safety integration	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>						
1.1.3.	Materials and products	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>						
1.1.4.	Lighting	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>						
1.1.5.	Design of machinery to facilitate its handling	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>						
1.1.6.	Ergonomics	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>						
1.1.7.	Operating positions	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>						
1.1.8.	Seating	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>						
1.2.	CONTROL SYSTEMS									
1.2.1.	Safety and reliability of control systems	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>						
1.2.2.	Control devices	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>						
1.2.3.	Starting	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>						
1.2.4.1.	Normal stop	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>						
1.2.4.2.	Operational stop	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>						
1.2.4.3.	Stopping the machine in an emergency	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>						
1.2.4.4.	Assembly of machinery	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>						
1.2.5.	Selection of control or operating modes	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>						
1.2.6.	Failure of the power supply	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>						
1.3.	PROTECTION AGAINST MECHANICAL HAZARDS									
1.3.1.	Risk of loss of stability	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>						
1.3.2.	Risk of break-up during operation	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>						
1.3.3.	Risks due to falling or ejected objects	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>						
1.3.4.	Risks due to surfaces, edges or angles	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>						
1.3.5.	Risks related to combined machinery	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>						
1.3.6.	Risks related to variations in operating conditions	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>						
1.3.7.	Risks related to moving parts	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>						
1.3.8.	Choice of protection against risks arising from moving parts	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>						
1.3.8.1.	Moving transmission parts	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>						
1.3.8.2.	Moving parts involved in the process	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>						
1.3.9.	Risks of uncontrolled movements	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>						
1.4.	REQUIRED CHARACTERISTICS OF GUARDS AND PROTECTIVE DEVICES									
1.4.1.	General requirements	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>						
1.4.2.	Special requirements for guards	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>						
1.4.2.1.	Fixed guards	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>						
1.4.2.2.	Interlocking movable guards	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>						
1.4.2.3.	Adjustable guards restricting access	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>						
1.4.3.	Special requirements for protective devices	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>						





Section	Requirements	To be complied with by the system integrator for the final machinery			Complied with for the scope of the partly completed machinery			Not relevant		
1.5.	RISKS DUE TO OTHER HAZARDS									
1.5.1.	Electricity supply									
1.5.2.	Static electricity									
1.5.3.	Energy supply other than electricity									
1.5.4.	Assembly error									
1.5.5.	Extreme temperatures									
1.5.6.	Fire									
1.5.7.	Explosion									
1.5.8.	Noise									
1.5.9.	Vibrations									
1.5.10.	Radiation									
1.5.11.	External radiation									
1.5.12.	Laser radiation									
1.5.13.	Emissions of hazardous materials and substances									
1.5.14.	Risk of being trapped in a machine									
1.5.15.	Risk of slipping, tripping or falling									
1.5.16.	Lightning									
1.6.	MAINTENANCE									
1.6.1.	Machinery maintenance									
1.6.2.	Access to operating positions and servicing points									
1.6.3.	Isolation of energy sources									
1.6.4.	Operator intervention									
1.6.5.	Cleaning of internal parts									
1.7.	INFORMATION									
1.7.1.	Information and warnings on the machinery									
1.7.1.1.	Information and information devices									
1.7.1.2.	Warning devices									
1.7.2.	Warning of residual risks									
1.7.3.	Marking of machinery									
1.7.4.	Instructions									
1.7.4.1.	General principles for the drafting of instructions									
1.7.4.2.	Contents of the instructions									
1.7.4.3.	Sales literature									
2.	SUPPLEMENTARY ESSENTIAL HEALTH AND SAFETY REQUIREMENTS FOR CERTAIN CATEGORIES OF MACHINERY									
2.1.	Foodstuffs machinery and machinery for cosmetics of pharmaceutical products									
2.2.	Portable hand-held and/or hand-guided machinery									
2.3.	Machinery for working wood and material with similar physical characteristics									
2.4.	Machinery for pesticide application									
3.	Supplementary essential health and safety requirements to offset hazards due to the mobility of machinery									
4.	Supplementary essential health and safety requirements to offset hazards due to lifting operations									
5.	Supplementary essential health and safety requirements for machinery intended for underground work									
6.	Supplementary essential health and safety requirements for machinery presenting particular hazards due to the lifting of persons									



## Appendix 2

### Information pertaining to the assembly instructions described in Annex VI, Directive 2006/42/EC

General designation	QuickMove
Model/type designation	ERS 50, non-driven roller conveyor elements
Unique identification number	

The assembly instructions provide the person incorporating the partly completed machinery described above into machinery, or assembling it with other parts to form the final machinery, with the necessary information, relating in particular to the safety-relevant interfaces, for correct assembly without endangering the health and safety of persons.

In addition to these assembly instructions, the relevant European Directives and national regulations must be taken into account.

The complete compliance documentation to be provided by the manufacturer consists of

- the present document "Declaration of Incorporation",
- all accompanying documents in printed form.