

SWISSLOG SPECIFICATIONS

WHOTUBE™ FOR PNEUMATIC TUBE SYSTEM STATIONS



WhoTube™ card swipe technology provides additional security for pneumatic tube system station access and secure transactions. The swipe of a valid access card unlocks the station control panel and can also unlock the Station Access Doors.

Due to ongoing improvement programs, Swisslog reserves the right of production or design change without notice or obligation.

Stations using WhoTube are prevented from sending by a default control setting. A valid access card is required to send from the station. Stations equipped with Station Access Doors are controlled using WhoTube as well.

Secure Transactions

To send a Secure Transaction:

1. Swipe access card.
2. Select "Badge Secure Transaction" from user menu.
3. Process transaction.
4. Station automatically locks if another transaction is not initiated within 20 seconds.

To receive a Secure Transaction, an access card must be swiped to release the carrier into the station bin.

All sender/receiver information is recorded with each transaction.

Features & Benefits

- > All WhoTube card swipes are recorded with the transaction
- > Sending capability is available only to approved users
- > Supports magnetic stripe, barcode, proximity & smart card technologies

WhoTube technology can be retrofitted to TransLogic tube systems using TL2009 software and integrated I.Q. panels.

For More Information in North America:

Swisslog Healthcare Solutions
Email: healthcare@swisslog.com
USA: (800) 764-0300
Canada: (877) 294-2831 | (905) 629-2400

©2010 Swisslog
CM# PTS-212

WWW.SWISSLOG.COM

swisslog