

SWISSLOG CUSTOMER SUPPORT BULLETINS

TRANSLOGIC STATION ACCESS DOOR



Swisslog's Station Access Door is designed to provide limited access to a station, offering added safety and security. Only authorized users with a valid PIN can open the door and gain access to the contents of the station interior.

The Station Access Door is secured by an electro-magnetic lock and can be opened by entering a valid PIN into the I.Q. Control Panel. The electro-magnetic lock releases and the I.Q. Panel LCD display notifies the user that the door is ready to be opened. If the user enters an invalid PIN, the LCD display informs the user that the PIN was invalid. After the door has been successfully opened, the electro-magnetic lock automatically resets, allowing the user enough time to send or receive as needed.

The Station Access Door is constructed of powder-coated steel with a clear polycarbonate window. The door is currently available for both 4-inch and 6-inch Recessed Stations using I.Q. Control Panels with Swisslog's Matrix or TL software. A mechanical Station Access door is available for stations not using I.Q. Control Panels.

Ordering Information the Station Access Door

6-inch Station Access Door (magnetic)	056-6792-01
6-inch Station Access Door (mechanical)	056-6792-03
4-inch Station Access Door (magnetic)	056-6792-02
4-inch Station Access Door (mechanical)	056-6792-04

Due to ongoing improvement programs, Swisslog reserves the right of production or design change without notice or obligation.

For More Information in North America:

Swisslog Customer Support
Email: orderentry@swisslog.com
USA: (800) 396-9666 | Fax: (303) 373-7871
Canada: (877) 294-2831 | Fax: (905) 629-2799

©2008 Swisslog
CM# CS-501

WWW.SWISSLOG.COM

swisslog