

HEALTHCARE SOLUTIONS

BEACON INVENTORY MANAGEMENT SYSTEM FOR OUTPATIENT PHARMACIES



Beacon Inventory Management System for outpatient hospital pharmacies ensures customer safety in a compact storage and retrieval solution via a unique pick-to-light system. Beacon stores more drugs in less space, while reducing labor, inventory costs and customer wait time. It organizes medications by activity and guides picking and stocking with innovative light direction and barcode verification technology.

Beacon is an installation-ready turnkey solution featuring a pick and put-to-light storage and retrieval system. Completely customizable, Beacon's flexibility ensures your valuable space is optimized and efficient.

Configuration Options:

- > Automated prescription filling
- > Fast moving oral solids shelves
- > Multi-bay work stations
- > Prescription management software
- > Bulk storage
- > High-density carousel
- > Automatic vial shredding

Benefits:

- > 100% of formulary in half the space
- > Fill accuracy
- > Barcode verification technology
- > Inventory accuracy
- > Decrease in fill times
- > Decrease in pharmacy footprint
- > Decrease in customer wait times
- > Decrease in technician training time
- > Decrease in inventory stocking levels
- > Decrease in expired medications
- > Simple, quick customer pick-up
- > Auto-alert for unclaimed prescriptions

swisslog

Beacon Inventory Management System For Outpatient Pharmacies

Turnkey Option

Installation of Swisslog's turnkey pharmacy is quick and easy. Beacon can be installed in just days with minimal disruption to your facility and staff. The modular system makes additions and reconfiguration simple.



Scan-Hang-Deliver

The simple pick-to-light inventory control system enables convenient and accurate prescription filling, distribution and restocking with barcode verification. The pick-to-light system's bright LED lights clearly identify the correct drawer for picking and stocking to ensure accurate medication picking. Numeric displays on the shelving specify the correct row and slot locations within the storage system for each bulk medication bottle.

Using Beacon, pharmacists simply fill the prescription using pick-to-light, scan the bar-coded hanging bag, and hang it on the carousel for retrieval. When the customer arrives, the LED light will indicate the correct bag for the specified customer.

Innovative Reporting

Beacon's software allows for real-time reporting. Numerous reports can be generated in seconds to check inventory levels, usage records, will call in/out management, will call expiration, unclaimed prescriptions and more.

Due to ongoing improvement programs, Swisslog reserves the right of production or design change without notice or obligation.

For More Information in North America:

Swisslog Healthcare Solutions
Email: healthcare@swisslog.com
USA: 800.764.0300 | Canada: 877.294.2831 or 905.629.2400



Swisslog Healthcare Solutions



SwisslogNA

WWW.SWISSLOG.COM